

# Elite Series Rail Kits

Years	Model	Bracket Number	
<b>Chevrolet/ GMC</b>			
1999-2007	Silverado/Sierra 1500, Except 8ft Bed (Classic)	30061	No Drill SW
2001-2007	Silverado/Sierra 1500 HD (Classic)	30061	No Drill
1999-2004	Silverado/Sierra 2500 Except 8 ft. Bed	30061	No Drill
2001-2010	Silverado/Sierra 2500 HD Except 8 ft. Bed	30061	Drill
2011-2019	Silverado/Sierra 2500 HD Except with OEM HD Towing Prep Package	30868	No Drill
2007-2010	Silverado/Sierra 3500 HD Except 8 ft. Bed	30061	Drill
2011-2019	Silverado/Sierra 3500 HD Except with OEM HD Towing Prep Package	30868	No Drill
<b>Dodge/Ram</b>			
2002-2008	Ram 1500 Except Mega Cab	30067	Drill
2002-2008	Ram 1500	30074	No Drill
2003-2012	Ram 2500 Except Mega Cab	30067	Drill
2010-2012	Ram 2500	30852	Drill
2003-2013	Ram 2500	30074	Drill
2003-2012	Ram 3500 Except Mega Cab	30067	Drill
2003-2012	Ram 3500	30074	Drill
2010-2012	Ram 3500	30852	Drill
<b>Ford</b>			
2004-2014	F-150	30064	Drill
1999-2010	F-250/F-350 Super Duty, Except Cab & Chassis	30073	Drill
2011-2016	F-250/F-350 Super Duty, Except Cab & Chassis	30126	No Drill
2008-2010	F-450 Super Duty, Except Cab & Chassis	30073	Drill
2011-2016	F-450 Super Duty, Except Cab & Chassis	30126	No Drill

SW=Do not install on truck with less than a 6' long bed unless trailer is equipped with a Sidewinder pin box.