

Outboard Installation Brackets and Kits

Years	Model	Outboard Rail Kit	Required Frame Kit	
Chevrolet/ GMC				
1999-2007	Silverado/Sierra 1500 (Classic)	30153	56007	SW
2007-2019	Silverado/Sierra 1500, Does not fit MagneRide Magnetic Ride Suspension	30153	56007	SW
2001-2007	Silverado/Sierra 1500 HD	30153	56007	
1999-2004	Silverado/Sierra 2500	30153	56007	
2001-2007	Silverado/Sierra 2500 HD, (Classic)	30153	56007	
2007-2010	Silverado/Sierra 2500 HD	30153	56007	
2008-2010	Silverado/Sierra 2500 HD, 6.6 ft. Bed	30153	56014	
2011-2019	Silverado/Sierra 2500 HD, Except with OEM HD towing Prep Package	30153	56001	
2001-2007	Silverado/Sierra 3500, (Classic)	30153	56007	
2007-2010	Silverado/Sierra 3500 HD	30153	56007	
2008-2010	Silverado/Sierra 3500 HD, 6.6 ft. Bed	30153	56014	
2011-2019	Silverado/Sierra 3500 HD, Except with OEM HD towing Prep Package	30153	56001	
Dodge/Ram				
2003-2013	Ram 2500	30153	56011	
2014-2020	Ram 2500	30153	56009	
2003-2012	Ram 3500	30153	56011	
2013-2018	Ram 3500, Except with RamBox Cargo Management System or w/Air Suspension	30153	56010	
Ford				
2004-2014	F-150	30153	56006	SW
2015-2020	F-150	30153	56034	SW
1999-2010	F-250/F-350 Super Duty, Except Cab & Chassis	30153	56005	
2011-2016	F-250/F-350 Super Duty, Except Cab & Chassis	30153	56016	
2017-2020	F-250/F-350 Super Duty, Except Cab & Chassis	30153	56017	
2008-2010	F-450 Super Duty, Except Cab & Chassis	30153	56005	
2011-2016	F-450 Super Duty, Except Cab & Chassis	30153	56016	
2017-2020	F-450 Super Duty, Except Cab & Chassis	30153	56017	

SW = Do not install on a truck with less than a 6' long bed unless the trailer is equipped with a Sidewinder Pin Box coupler