

Required Bracket Kits for Pro Series Rails

Additional Brackets may be required for installation of Pro Series Rails

Years	Model	Required Upgrade Kit	
Chevrolet/			
1973-2000	C/K Series	---	
1999-2007	Silverado/Sierra 1500 (Classic)	---	
2007-2019	Silverado/Sierra 1500 Except High Desert Package	---	
2001-2007	Silverado/Sierra 1500 HD (Classic)	---	
1999-2004	Silverado/Sierra 2500	---	
2001-2019	Silverado/Sierra 2500 HD Except with OEM HD Towing Prep Package	---	
2001-2007	Silverado/Sierra 3500 (Classic)	---	
2007-2019	Silverado/Sierra 3500 HD Except with OEM HD Towing Prep Package	---	
All	with Composite Beds	58208	
Dodge/Ram			
1973-1993	D-Series	---	
1994-2004	Dakota	---	
1994-2001	Ram 1500	---	
2002-2008	Ram 1500	58023	
2009-2012	Ram 1500	58386	SW
2013-2019	Ram 1500, Except Air Suspension or ECO Diesel Eng.	58386	MB,SW
2014-2019	Ram 1500, Except Air Suspension	58523	MB,SW
1994-2002	Ram 2500	---	
2003-2012	Ram 2500 with overload springs	58186	
2003-2013	Ram 2500 Except with overload springs	58023	
2014-2020	Ram 2500	58522	
1994-2002	Ram 3500	---	
2003-2012	Ram 3500 with overload springs	58186	
2003-2012	Ram 3500 Except with overload springs	58023	
2013-2018	Ram 3500	58520	
Ford			
1975-1983	F-100	---	
1975-1996	F-150	---	
1997-2003	F-150 Styleside, Except Supercrew	---	
2004-2014	F-150	58426	
2015-2020	F-150	58531	
2004	F-150 Heritage, Styleside	---	
1975-1996	F-250/F-350	---	
1977-1997	F-250/F-350, Heavy Duty	---	
1997-1999	F-250/F-350, Styleside	---	
1999-2016	F-250/F-350, Super Duty, Except Cab & Chassis	---	
2008-2016	F-450 Super Duty, Except Cab & Chassis	---	
Nissan			
2004-2015	Titan	58405	SW
Toyota			
2000-2006	Tundra, Regular Cab 8ft. Bed	58197	
2007-2019	Tundra	58309	

MB = Will not fit models equipped with air suspension package.

SW=Do not install on truck with less than a 6' long bed unless trailer is equipped with a Sidewinder pin box.

--- = No additional Bracket KIT Required